

Frames (Perfex™ Curvilinear)

Applicable Products:

PXCU Series
Knocked Down

1. Slide corner brackets into top frame sections as shown, with raised indents facing outwards (fig. A). Repeat for the bottom section.
2. Press top and bottom frame sections into the side section (fig. B).
3. Press side half sections into the frame to complete unit assembly (fig. C).
4. Slide graphic into the frame (fig. D).

