

Straight Flat Wall™ - FW108

All tube-ends are labeled with a number sticker. Tube-ends should be connected 1 to 1, 2 to 2, 3 to 3, etc.

1. Connect upright sections together.
2. Slide corner bracket over upright until push button clicks into place.
3. Slide upright over base upright until push button clicks into place.
4. Slide upper T-section over center upright until push button clicks into place. Repeat for lower T-section.
5. Press bottom crossbar sections in between uprights until push buttons click into place.
6. Press top crossbar sections in between uprights until push buttons click into place.
7. Slide pillowcase graphic over frame and zipper at bottom to complete unit assembly (not shown). Make note of zipper spacing for step 8, droop prevention.
8. Using the holes located on the bottom of the graphic (if included), fasten the small threaded base to the female threaded connection located on the underside of the crossbar section adjacent to the center T-sections. Adjust height to ensure center of the graphic is level with side uprights.

NOTE: Model shown below may differ from your model. Although the number of upright sections may change, assembly instructions remain the same.

