

Exhibitor Products (Pop-Up Collage Frames™)

Applicable Products:

LG Series

1. Lay pop-up frame on ground (fig. A-1) and pull straight up to expand (fig. A-2).
2. Connect magnetic fasteners to hold frame tight in place (fig. B-1).
3. Attach positive lock to prevent unintended opening (fig. B-2).
4. Attach graphic flags by fitting button holes over knob (fig. C).

NOTE: In situations where a graphic stretches over a hub, the knob on the hub will cause the graphic to have a "tent" effect. To fix this, simply unscrew the standard knob and replace it with a flat knob wherever the "tent" effect takes place (fig. D-1 & D-2).

NOTE: Always remove positive lock before closing pop-up frame.

NOTE: Unit may differ from model shown below, but assembly is the same.

